

Addendum - TS2500 Operators Manual: Omitting Zones

Introduction

The 2500 allows you to set wards with circuits omitted (if this function has been enabled by the Engineer). When you unset the system the 2500 does not automatically rearm the circuits. If you want the circuits to be reinstated, you must rearm the circuits from the keypad before setting the ward again. See “Omitting Circuits” on page 29 of the 2500 Operators Manual.

Correction to the Operators Manual

This correction applies to .18615 and 496496 Issue 1.

On page 17 of the Operators Manual the last paragraph reads:

“When the ward(s) is unset all previous omitted circuits are reinstated.”

This paragraph should now read:

“When you unset the ward(s) make sure all previously omitted circuits are armed before setting the system again, see “Omitting Circuits” on page 29.”

This correction will be included in issue 2 onward of 496496.

Cooper Security Ltd. Security House. Vantage Point Business Village. Mitcheldean. Gloucestershire. GL17 0SZ
Product Support (UK) Tel: +44 (0)1594 545556. Between 09:00 and 17:30 Monday to Thursday, 09:00 to 17:00
Friday. Product Support Fax: +44 (0)1594 545401.

